

Engineering

Information transfer to an upper system

FSF F -1 FSF F -2 FSF F -3

Interface for linking with upper systems.

Logistics

Pick the right amount of the right material, at the right time

FSF E -1

Automatically check out materials at the right amount and at the right time using automated warehouses.

Automatic setup

FSF E -2 FSF E -3 FSF E -4

Solutions for automating setup work for materials such as part reels.

Automatic changeover for the entire line

FSF A -1 FSF A -2

Perform automatic line changeover for the entire line by reading kanban or panel IDs.

Process

Print inspection result feedback

FSF D -1 FSF D -4

Feedback from SPI inspection results is sent back to the printer to maintain stable printing.

Optical inspection result feedback

FSF D -2

Feedback from AOI inspection results is sent back to the mounters to maintain stable placement.

Board skip feed forward

FSF D -3

Board skips are performed at the mounters based on the SPI inspection results.

Remote operation

FSF C -1

Resume production and recover from error stops in centrally managed areas.

Automatic maintenance and management

FSF E -5 FSF E -6 FSF E -7

Solutions for managing maintenance and automating the maintenance work for nozzles, feeders, and heads.

Analytics

Monitor the floor status in real time

FSF B -1

Multiple SMT lines can be monitored collectively, also detailed statuses of each line and machine can be checked.

Line status realtime monitoring

FSF B -2

Display the status of each SMT line and provide guidance for countermeasures when problems occur.

Countermeasure support

FSF B -3

Display information of printers, mounters, and inspection machines in a unified manner to support analysis and improvements.

Remote monitoring

FSF B -4

Check the statuses of SMT factories and lines even when off site.

Traceability for the entire line

FSF H -1

Collect and manage traceability data for entire SMT lines.

Paving the way to a new manufacturing era

FUJI Smart Factory with Nexim



FUJI CORPORATION

19 Chausuyama, Yamamachi, Chiryu, Aichi, 472-8686 Japan

Tel: +81-566-81-2110

Fax: +81-566-83-1140

- The contents of this catalog are subject to change without notice.
- The information in this catalog is current as of June, 2019.
© 2019 FUJI CORPORATION. All Rights Reserved.



Get optimum production through well-prepared production cycles

